

BAZOONGI KIDS®

" Kids Cottage "

Garden House

Item: #T11116


"Kids Cottage" is our best selling Bazoongi® Kids Play Structure. It is made of industry approved spun-bonded material with bright and rich colors. Our innovative design allows easy assembly, and the revolutionary G3 poles add strength to the structure. Enjoy your Bazoongi® Kids Cottage and be sure to contact us for any further information.

PLEASE READ ALL OF THE DIRECTIONS PRIOR TO ASSEMBLY. DO NOT APPLY EXCESS FORCE TO THE POLES DURING ASSEMBLY. Assemble only with adult supervision.

Parts List

2 - Long Blue Poles	1 - Long Grey Pole
2 - Short Blue Poles	4 - Short Grey Poles
4 - Red Poles	1 - Cottage Tent Body
2 - Yellow Poles	1 - Floor Sheet

1. Assemble the Cottage Frame completely BEFORE placing the Cottage Body onto the frame.
2. Straighten all of the segments of the G3 poles with shock cords.
3. Using the 2 Long Blue Poles and the 2 Short Blue Poles, Press the poles into the corner fittings to make a rectangular base (Fig. A).
4. Press the 4 Red Poles into the Upright slots of the corner connectors on the rectangular base (Fig. B).
5. Attach the Yellow Poles to the top of the Red Poles (Fig. C).
6. Insert the 4 Short Grey Poles into the connectors of the Yellow Poles (Fig. D).
7. Attach the Long Grey Pole to the 4 Short Grey Poles using the attached connectors (Fig. E).
8. Slide the material of the Cottage Body OVER the assembled frame.
9. Flip the Cottage onto its side and then slide the bottom corners of the frame into the pockets on the cottage body.
10. Attach the floor sheet below the Cottage by attaching the velcro sewn onto the cottage body and the floor sheet.



Now, you can attach all seven colorful detachable flowers onto tent body by attaching the Velcro sewn on the tent body and the detachables themselves.

Care & Safety Instructions

- . This item is for indoor use only. Direct Sunlight can degrade the material.
- . Do not Wash! Clean only with damp cloth!
- . Never Store Wet. Store in a cool dry location.
- . Keep this tent away from heat sources or open flame.

WARNING! "Keep All Flame And Heat Sources Away From This Tent Fabric. This Tent Is Made With Fabric That Meets CPAI - 84 Specifications For Flame Resistance. It Is Not Fire Proof. The Fabric Will Burn If Left In Continuous Contact With Any Flame Source. The application of any foreign substance to the tent fabric may render the flame resistant properties ineffective."