

this product Be sure to read and follow all instructions carefully before using Thank you for purchasing the N-STRIKE NITE FINDER EX-3 blaster.

1.5VAA or R6 size

X2 BATTERIES REQUIRED


Alkaline batteries recommended. Phillips/cross head screwdriver (not included) needed to insert batteries.

NOT INCLUDED

Do not aim at eyes or face.

Use only darts designed for this product Do not modify darts or dart blasters.


N-STRIKE NITE FINDER EX-3 BLASTER WITH 3 SUCTION DA



## INSERTING THE BATTERIES


Be sure to fully tighten the screw. size batteries. Alkaline batteries recommended. Replace door Screw will remain attached to door. Insert 2 fresh "AA" or R6











Pull trigger about halfway to see the light beam. This works best in low-light conditions.

## MPORTANT: BATTERY INFORMATION

- 1. Always follow the instructions carefully. Use only batteries specified and them correctly by matching the + and - polarity markings.
- Do not mix old batteries and new batteries or standard (carbon-zinc) with
- ယ Remove exhausted or dead batteries from the product.
- Remove batteries if product is not to be played with for a long time
- Do not short-circuit the supply terminals.
- Should this product cause, or be affected by, local electrical interference, from other electrical equipment. Reset (switching off and back on again o re-inserting batteries) if necessary.
- 7. RECHARGEABLE BATTERIES: Do not mix these with any other types of batt remove from the product before recharging. Recharge batteries under adu DO NOT RECHARGE OTHER TYPES OF BATTERIES



\*Compatible with Tactical Rail accessories from other N-STRIKE® blasters (sold separately)

Product and colors may vary.
© 2009 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.
U.S. Pat. No. 5529050.
614960801 P/N 6976530000





