

IMPORTANT

EL52103/EL52113/EL52203/EL52213/EL52253/EL52303/ EL52313/EL52353/EL52403/EL52503

The following are some common features you may want to set or use.

For complete installation and operation instructions, see the **Quick start guide** provided in the product package, or see the online **User's manual** at www.telephones.att.com/manuals.

Record your own announcement

You can use the preset announcement to answer calls, or replace it with your own recorded announcement.


1. Press **MENU** when idle >> scroll to **Answering sys** >> press **SELECT** twice.
2. Press **7** to record >> speak towards the microphone >> press **5** when done.



Set number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5 or 6 rings; or toll saver.

1. Press **MENU** when idle >> scroll to **Answering sys** >> press **SELECT**.
2. Scroll to **Ans sys setup** >> press **SELECT**.
3. Scroll to **# of rings** >> press **SELECT**.
4. Scroll to choose **2, 3, 4, 5, 6** or **Toll saver** >> press **SELECT**.




Set handset ringer volume

1. Press **MENU** when idle >> scroll to **Ringers** >> press **SELECT** twice.
2. Scroll to sample each volume level >> press **SELECT**.

Review and dial a number in the caller ID log


1. Press **CID** when idle >> scroll to browse to the desired entry.
2. Press **TALK** or **CALL** to dial.



Clear missed call indicator

When you have incoming calls that have not been answered, the handset shows **XX missed calls**.

If you do not want to review the missed calls one by one, press and hold **CANCEL** on the idle handset to erase the missed call indicator.




Are you a new cable or VoIP subscriber?

If your answer is yes, the existing telephone jacks in your home may no longer work. Your cable/VoIP service provider uses a different connection, separate from your old traditional telephone service, to connect the modem/router/terminal adapter installed in your home.

To allow all existing telephone jacks to work, contact your telephone service provider for solutions, such as rewiring services (fees may apply).

If your answer is no, your existing telephone jacks will continue to work as normal.



Did you subscribe to voicemail service from your telephone service provider?

Your telephone has a built-in answering system and supports voicemail feature offered by your telephone service provider (subscription required, and fees may apply). Refer to **Answering system and voicemail indicators** in the user's manual for more details.

To use the built-in answering system:

Refer to the **Quick start guide** provided in the product package on how to record your outgoing announcement, retrieve messages and other related operations. You may also view the **User's manual** at www.telephones.att.com/manuals for complete instructions.

To use the voicemail:

To retrieve your voicemail messages, you typically dial an access number provided by your telephone service provider, and then enter a security code. Contact your telephone service provider for instructions on how to configure the voicemail settings and listen to messages.